

KOBE TOOLS

To Suit	Part Number	Description	Order Code	Offer Price/1
MBS1613L Air Sander	60614	Rotor	KBE-298-1205S	£9.76
	61216	Rotor Blades (4)	KBE-298-1211S	£4.00
	61218	Cylinder	KBE-298-1217S	£39.09
MBS1620L Air Sander	62015	Rotor	KBE-298-1379S	£13.57
	62016	Rotor Blades (4)	KBE-298-1382S	£5.15
	62018	Cylinder	KBE-298-1388S	£42.35
NB160 Air Nibbler	20315	Rotor	KBE-298-0569S	£9.02
	SM-51216	Rotor Vanes (4)	KBE-298-0040S	£4.00
	20318	Cylinder	KBE-298-0578S	£5.65
PA1825 Air Polisher	830020	Rotor	KBE-298-2441S	£13.79
	829019	Rotor Blades	KBE-298-2435S	£9.02
	829022	Cylinder	KBE-298-2447S	£13.27
RP1875 Air Riveter	SG081-19	Return Spring	KBE-298-0698S	£3.94
	SG0810-1A	Nosepiece 3/16"	KBE-280-0031A	£1.09
	SG0810-1B	Nosepiece 5/32"	KBE-280-0034A	£1.09
	SG0810-1C	Nosepiece 1/8"	KBE-280-0037A	£1.09
SH120 Air Shear	20415	Rotor	KBE-298-0374S	£9.02
	20416	Rotor Blades (4)	KBE-298-0377S	£0.88
SP1825 Air Scrdrv	80215	Rotor	KBE-298-2255S	£9.02
	SM-70916R	Rotor Blades (5)	KBE-298-0572S	£4.51
	80218	Cylinder	KBE-298-2261S	£9.39
SR375 Air Ratchet	SM-30115	Rotor	KBE-298-0037S	£8.26
	SM-51216	Vanes (4)	KBE-298-0040S	£4.00
	SM-30118	Cylinder	KBE-298-0046S	£3.75
SR500 Air Ratchet	SM-30115	Rotor	KBE-298-0037S	£8.26
	SM-51216	Vanes (4)	KBE-298-0040S	£4.00
	SM-30118	Cylinder	KBE-298-0046S	£3.75
SS1525 Air Scrdrv	2025	Rotor	KBE-298-0872S	£6.77
	2024	Rotorblade	KBE-298-0869S	£5.26
	2023	Cylinder	KBE-298-0866S	£10.52



To Suit	Part Number	Description	Order Code	Offer Price/1
1923BD (110V) Planer	181021-2	Carbon Brushes	MAK-298-1322H	£2.20
	651239-4	Trigger Switch	MAK-298-7533K	£5.00
	511936-3	Armature	MAK-298-5467L	£38.20
1923BD (240V) Planer	181021-2	Carbon Brushes	MAK-298-1322H	£2.20
	651239-4	Trigger Switch	MAK-298-7533K	£5.00
	511939-7	Armature	MAK-298-5467S	£38.20
3612 (110V) Router	191953-5	Carbon Brushes	MAK-298-1558S	£3.80
	651419-2	Trigger Switch	MAK-298-7558E	£13.40
	516586-9	Armature	MAK-298-5835P	£70.00
3612 (240V) Router	191953-5	Carbon Brushes	MAK-298-1558S	£3.80
	651419-2	Trigger Switch	MAK-298-7558E	£13.40
	516589-3	Armature	MAK-298-5835Z	£70.00
3612C (110V) Router	191953-5	Carbon Brushes	MAK-298-1558S	£3.80
	651419-2	Trigger Switch	MAK-298-5835C	£54.90
	516505-5	Armature	MAK-298-5827X	£98.50
3612C (240V) Router	191953-5	Carbon Brushes	MAK-298-1558S	£3.80
	651923-1	Trigger Switch	MAK-298-7651E	£8.90
	516579-6	Armature	MAK-298-5835C	£54.90
3703 (110V) Trimmer	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	651467-1	Trigger Switch	MAK-298-7568D	£8.60
	511916-9	Armature	MAK-298-5466E	£38.80
3703 (240V) Trimmer	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	651467-1	Trigger Switch	MAK-298-7568D	£8.60
	511919-3	Armature	MAK-298-5466K	£59.70
4304T (110V) Jigsaw	191962-4	Carbon Brushes	MAK-298-1560D	£2.20
	651922-3	Trigger Switch	MAK-298-7651B	£7.60
	517099-3	Armature	MAK-298-5866G	£43.90
4340FCT (110V) Jigsaw	191962-4	Carbon Brushes	MAK-298-1560D	£2.20
	650202-4	Trigger Switch	MAK-298-7455M	£17.80
	517396-7	Armature	MAK-298-5875R	£43.90
4340FCT (240V) Jigsaw	191962-4	Carbon Brushes	MAK-298-1560D	£2.20
	650202-4	Trigger Switch	MAK-298-7455M	£17.80
	517398-3	Armature	MAK-298-5875W	£43.90
6337DWDE Cordless Drill	191971-3	Carbon Brushes	MAK-298-1562J	£2.70
	618144-2	Switch Unit	MAK-298-6890C	£21.20
	619115-8	Armature	MAK-298-6892E	£13.00
	KEN4404740K	Chuck	KEN-440-4740K	£21.13
	193101-2	Battery	MAK-280-2710T	£76.56
	DC1411	Charger	MAK-280-8405E	£57.20

To Suit	Part Number	Description	Order Code	Offer Price/1
6343DWDE Cordless Drill	191971-3	Carbon Brushes	MAK-298-1562J	£2.70
	651968-9	Trigger Switch	MAK-298-7658A	£21.00
	629729-5	Armature	MAK-298-6985G	£25.90
	KEN4404740K	Chuck	KEN-440-4740K	£21.13
	193102-0	Battery	MAK-280-2711V	£89.76
	DC1801	Charger	MAK-280-8406Q	£70.40
6347DWDE Cordless Drill	638143-4	Switch Unit	MAK-298-7050P	£21.20
	KEN4404740K	Chuck	KEN-440-4740K	£21.13
	193102-0	Battery	MAK-280-2711V	£89.76
	DC1801	Charger	MAK-280-8406Q	£70.40
8433DWDE Cordless Drill	191964-0	Carbon Brushes	MAK-298-1560X	£2.70
	651939-6	Trigger Switch	MAK-298-7652K	£27.50
	629734-2	Armature	MAK-298-6985Q	£24.80
	KEN4404740K	Chuck	KEN-440-4740K	£21.13
9015B (110V) Grinder	191963-2	Carbon Brushes	MAK-298-1560G	£4.00
	651148-7	On/Off Switch	MAK-298-7516Y	£15.80
	516331-2	Armature	MAK-298-5816D	£38.00
	125097-9	Guard	MAK-298-0540R	£8.10
9015B (240V) Grinder	191963-2	Carbon Brushes	MAK-298-1560G	£4.00
	651149-5	On/Off Switch	MAK-298-7517C	£15.80
	516334-6	Armature	MAK-298-5816P	£38.00
	125097-9	Guard	MAK-298-0540R	£8.10
9031 (240V ONLY) Sander	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	631185-7	Trigger Switch	MAK-298-7007K	£17.80
	517149-4	Armature	MAK-298-5867D	£43.00
9046 (110V) Sander	191962-4	Carbon Brushes	MAK-298-1560D	£2.20
	651263-7	Trigger Switch	MAK-298-7536B	£17.80
	516211-2	Armature	MAK-298-5812G	£23.30
	162172-0	Sander Pad	MAK-298-1202W	£28.40
9046 (240V) Sander	191962-4	Carbon Brushes	MAK-298-1560D	£2.20
	651263-7	Trigger Switch	MAK-298-7536B	£17.80
	516214-6	Armature	MAK-298-5812N	£50.10
	162172-0	Sander Pad	MAK-298-1202W	£28.40
9069F (110V) Grinder	191957-7	Carbon Brushes	MAK-298-1559C	£7.00
	651148-7	Trigger Switch	MAK-298-7516Y	£15.80
	518494-0	Armature	MAK-298-5957M	£34.50
	156215-5	Guard	MAK-298-0929K	£8.10
9069F (240V) Grinder	191957-7	Carbon Brushes	MAK-298-1559C	£7.00
	651149-5	On/Off Switch	MAK-298-7517C	£15.80
	518495-8	Armature	MAK-298-5957P	£34.70
	150063-7	Guard	MAK-298-0682R	£21.10
9523NB (110V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	415952-6	On/Off Switch	MAK-298-4850J	£1.10
	517301-4	Armature	MAK-298-5872X	£41.80
	165187-6	Guard	MAK-298-1255W	£4.40
9523NB (240V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	415952-6	On/Off Switch	MAK-298-4850J	£1.10
	517303-0	Armature	MAK-298-5873A	£41.80
	165187-6	Guard	MAK-298-1255W	£4.40
9524NB (110V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	415952-6	On/Off Switch	MAK-298-4850J	£1.10
	517301-4	Armature	MAK-298-5872X	£41.80
	165053-7	Guard	MAK-298-1248S	£3.00
9526PBK (110V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	651947-4	On/Off Switch	MAK-298-7652D	£3.70
	517305-6	Armature	MAK-298-5873D	£26.80
	165187-6	Guard	MAK-298-1255W	£4.40
9526PBK (240V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	651947-4	On/Off Switch	MAK-298-7652D	£3.70
	517309-8	Armature	MAK-298-5873J	£26.90
	165187-6	Guard	MAK-298-1255W	£4.40
9527NB (110V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	415952-6	On/Off Switch	MAK-298-4850J	£1.10
	517305-6	Armature	MAK-298-5873D	£26.80
	165053-7	Guard	MAK-298-1248S	£3.00
9527NB (240V) Grinder	191940-4	Carbon Brushes	MAK-298-1556A	£3.00
	415952-6	On/Off Switch	MAK-298-4850J	£1.10
	517309-8	Armature	MAK-298-5873J	£26.90
	165053-7	Guard	MAK-298-1248S	£3.00
BHR200 SHF Cordless Drill	191971-3	Carbon Brushes	MAK-298-1562J	£2.70
	651990-6	Trigger Switch	MAK-298-7662Z	£23.00
	193127-4	Battery	MAK-280-2730M	£118.80
	DC245A	Charger	MAK-280-8401A	£149.60
BO4553 (110V) Sander	191627-8	Carbon Brushes	MAK-298-1540G	£2.20
	651523-7	Trigger Switch	MAK-298-7580X	£17.80
	517080-4	Armature	MAK-298-5865A	£23.30
	151236-5	Base Plate	MAK-298-0700T	£5.20
BO4553 (240V) Sander	191627-8	Carbon Brushes	MAK-298-1540G	£2.20
	651523-7	Trigger Switch	MAK-298-7580X	£17.80
	517084-6	Armature	MAK-298-5864W	£23.30
	151236-5	Base Plate	MAK-298-0700T	£5.20

Power Tool Spares